



## BPTC Series Brake Pad Thermocouple Installation Guide:

1. Drill thru-hole in pad from backplate side using #31 drill bit (0.120")
2. Route wires through hole from braking pad surface side and set cap flush with pad by lightly tapping with a hammer
3. Sink cap depth about 1 to 2 mm into the pad surface using a nail set or punch, depth may need to be adjusted as brake pad wears

