
WPTC-ST WELD PAD THERMOCOUPLE INSTALLATION GUIDE:



1. Pad can be **clamped** onto pipe surface with a clamp.

- 2. Pad can be **brazed** onto surface along its outer edges.
- 3. Pad can be **spot welded** along edges, starting in the center and working out towards outer edges.


SPOT WELDING:



CORRECT BENDING OF FLEXIBLE STEM:




Minimum Bend Radius (**R**) = 3/16" (0.187")



INCORRECT BENDING OF FLEXIBLE STEM:







43996 Woodward Avenue Suite 200 Bloomfield Hills, MI 48302 USA Phone: 248-636-1515 · Fax 248-636-4969 Email: sales@TheSensorConnection.com Web: www.TheSensorConnection.com